

2 WIRES (CRISS-CROSS) ACROSS FRAME  
AND GO THRU HOLES IN 2X8. USE A BOLT  
TO TWIST THE WIRE AT EACH END AROUND  
THE BOLT TO PULL THE 2X8's TOGETHER

