



Slope of this angle is the same as the IT. This is where the dome bricks will sit

Outside of domebrick use IT to trace outside

Front top edge of arch

Inside of dome brick use IT to trace inside arch

Inside surface of dome can use IT to trace arc

Tapered Arch Brick looking sideways

Blank tapered arch brick before all the cuts to the example left.

